



MAC Motor | AERF Control box

Connections

- ① | Connect wires 1, 2, 3, 4 and 5 to the corresponding terminals of the limit switch



- ② | Control board wiring diagram




- ③ | Image of the final control board wiring connections




Programming procedures

- ① | Remote control (transmitter) programming



- ② | Manual travel switch programming



Assembly
manual
MAC Motor

